


SAFETY SW



CHARGING COIL  
internally connected to ground



GND

HV

KILL SWITCH

GND



PICKUP COIL



TACHOMETER




IGNITION COIL

GND



NGK

SAFETY SW



CHARGING COIL  
NOT internally connected to ground




GND

HV

KILL SWITCH

GND



PICKUP COIL



TACHOMETER



IGNITION COIL

GND



NGK